



Reference

How to install the leads on a 1/4" input jack.

1. White wire is "Hot" and is soldered to the "Tip" of the input jack.
2. Black wire is "Ground" and is soldered to the "Jacket" of the input jack.

Refer to image below for clarification.

